





Change Language: English by default. Phone UI change path: Menu --> Basic Setting --> Language.

1. Configuring network

Dynamic mode by default. Phone UI change path: Menu --> Advanced Setting (default password 123456) --> Network -->IP Config -->IPv4 settings --> IPv4 Mode.

2. Configuring account

Users can configure account via phone UI or WEB UI. WEB UI example.

Step 1: Pressing "OK" key to view the IP address

Step 2: Entering https://IP address on the browser. Login with "admin" and password "123456"

Step 3: Configuring account as below

≡	Account:	Account1 ~	
Status	Account Active:	•	
密 Account 🔷	Account Status:	Registered	
Basic	SIP Label Name:		0
Codec	Display Name:		0
Advanced	User Name:	52009	?
🌐 Network 🗸 🗸	Register Name:	52009	0
Provision	Password:	•••••	0
🚰 Phone Keys 🛛 🗸	SIP Server:	192.168.1.100	0
🌣 Settinas 🗸 🗸	SIP Server Port:	5060	0

Note: Marked items are mandatory. Please contact service provider for detail.

Step 4: Account status shows "Registered" when the SIP account is registered successfully.